

LUNAR 590 MIRROR

SKU: ZL590

INCLUDES

Mirror. Leather Strap. ZAVEDO Disc. Screw Rivet. Gib Anchor. Countersunk Square Head Screw.

INSTALLATION

- Locate stud preferably and screw the Disc Base directly into vertical stud at a height that suits. You can screw directly to solid panels. With masonry you will need a masonry anchor instead of a GIB anchor.
- If a nog or stud is not available screw GIB anchor into the GIB so is flush at a location that suits. Screw fastener into the GIB to fix the disc.
- Assemble Leather, slot in place then screw the Disc Cap through the hole in the leather.
- If the mirror is in a breeze way you can use double stick on the leather tabs which are located on the back of the mirror to stop it fluttering in the wind.

