

INSTALLATION GUIDE RAPID outer rim liner







Tools: Ruler, Scissors, Plastic card/Squeegee

- 1. This design uses 3 curved lines per side per rim (6 curved lines per wheel for both sides).
- 2. Please note that the design is MIRRORED so that each side has a similar pattern when fully assembled.
- 3. Clean outer rim area with soap and water. Dry completely. Ensure that there is no grime or dirt left as this would impair adhesion of the sticker.
- 4. Cut out each curved line individually as close to the colored sticker as possible
- 5. One wheel contains two sides. Please use 3 curved lines for each side of a rim.
- 6. When you are sticking the individual curves lines, use a 4.5 cm SPACE/GAP between the first and second curved line.
- 7. Take one curved line and peel it away from backing paper.
- 8. Align the bottom curve of sticker with the innermost curve of the rim (nearer to the hub).
- 9. Lightly tap the sticker and evaluate if the sticker is correctly aligned. You can re align the sticker if it is misaligned. Be careful though.
- 10. Use a Plastic card/Sqeegee to apply pressure to the sticker and run the card over the sticker 2 times.
- 11. Peel away clear transfer tape.
- 12. Repeat 2 times for the remainder curved lines for that side of the rim.
- 13. Before starting on the opposite side of the rim, please ensure that you used the mirrored design of the same color at the same starting point to ensure a matching pattern.
- 14. Repeats steps 6 to 13 and then start on the subsequent wheel.

ADDITIONAL INFO

This guide is used for Rapid, Rapid Mod 1 and 2

Please watch this video as a guide: http://www.youtube.com/watch?v=jf062YMmBA4