

website: www.bartact.com phone: 951-319-4008 email: orders@bartact.com

***After opening the box, check to make sure you have all pieces for both front seat covers. If you ordered the tactical seat covers, they may come with MOLLE pouches.

1) BOTTOM COVER INSTALL - For ease of install, both driver and passenger seat cover bottoms are the same.

I) Begin by fitting the bottom seat cover over the seat, tuck the center section between the top and bottom portions of the seat, and tuck the side into the plastic







II) Most difficult part - There are 2 elastic loops attached to hooks on the bottoms of each seat. Normally, you would be able to simply unhook these, but the locations of the SRS airbag & electric seat (on some models) wires don't make this as easy. First, use a flathead screwdriver to loosen and remove the wire's automotive fasteners. Then pull the red release tab on the connectors and pull them apart as shown below.



III) At this time, you can remove the elastic straps, the reconnect the wires and fasteners. Tuck the bottom curtain and elastic loops backwards and under the rear of the bottom seat cover, & connect the front and rear side release buckles then tighten them. Next, take the 550 paracord around the sides, slide through the sewn tabs on the seat cover, pull them tight, and tie them in place.



2) TOP COVER INSTALL -

I) Remove headrests by depressing plastic clips on both headrest posts. Then match up the top sections with their corresponding sides. Each top has an opening for the SRS air bag. MAKE SURE the opening is on the outer side of the seat, and not facing towards the midde of the vehicle.





III) Slide the Top on the seat, making sure it is centered. (Check again to make sure the air bag opening is facing the outside of the Bronco). Push the bottom front of the seat cover through the back of the seat. Pull back tightly, especially towards the outsides of the seat, and secure the hook and loop between the front and back sections until it is snug.





3) HEADREST COVER INSTALL - The headrest covers for Driver & Passenger are the same ***WE DO NOT PRE-CUT HEADREST HOLES BECAUSE OF DIFFERENT JIGS USED BY OEMS

Once the top cover is centered and securely in place, feel for the plastic puck under the cover. Using a razor blade, cut an 'X' slightly smaller than the plastic puck itself. (Don't worry. Our material has rip-stop, so it will not continue to tear once it's cut). After making the cut, tuck the material around the plastic puck until the plastic covers the openings.

Slide the headrest covers over the heatrests and secure the hook and loop. Reinstall the headrests onto the seats, and your covers are now installed, and ready to use!

