

*****IF YOU DO NOT HAVE A FOLD DOWN ARM REST, PLEASE SKIP TO THE SECOND ROW OF PHOTOS ON THE RIGHT SIDE OF THIS PAGE**



Tuck Cover behind armrest at top, slide bottom of the cover under the armrest, and attach the velcro



Once attached, make sure the armrest cover is centered and secured on the deges



Secure the inside edge between the 60 & 40 sections of the bench as shown



Install headrest cover and attach velcro



Fold down the armrest and slide over the armrest cover. Then slide the velcro piece from the armrest cover though the bottom and attach both pieces at the top.



Then do the same with the center headrest



Install the smaller section in a similar fashion, and you are ready to go after reattaching the center seat belt