



# 2018+ Jeep Wrangler JL/JLU Tailgate MOLLE Panel Installation



1) Using a flathead screwdriver, gently pop off the top tailgate panel



2) At the bottom of the Bartact panel pull the plastic tabs to open them slightly wider



3) Starting with the left or right side, insert all 4 plastic tabs into the bottom slot they line up with



\*\*\*It should look like this after all 4 tabs are inserted



4) Flip up the panel and slide over the plastic pins



5) Finger tighten the 3 included torx bolts, and then finish tightening them with a torx bit



6) Install your MOLLE Gear however you would like