

HOW TO RETRO-FIT TO THE NEW **BA-ICE** CONNECTOR



Remove the lamp connector base from the lamp harness on the BA-ICE-S.
Remove the sleeve bolt and place the ring adapter on the chamber.
Secure the ground wire to the chamber.



Screw the retaining nut on to the chamber.





Attach the lamp to the lamp harness and lower the lamp into the chamber.



System with new BA-ICE-S