



8700JP Installation Instructions

Typical Installation



Normal installation requires only a few tools, takes less than 15 minutes.

Installation Warning

If you feel uncomfortable installing this product, we recommend having a professional complete the installation. Eagle Lights LLC is not liable for any damage to the product or vehicle due to an improper installation. If you have questions about the installation, please feel free to call us at 1-800-921-3162 or email us at Support@EagleLights.com.

Installation:

Below are steps for a typical installation on most Harley Davidson models. Steps may be different depending on the model. Please ensure you have read through the instructions and understand them clearly before attempting the installation.

 WARNING! 
<ul style="list-style-type: none">● To prevent possible electrical shock, disconnect the negative battery terminal before installing this product.

1. Remove the upper splash shield by removing the clips with a flathead screwdriver.
2. Remove the four bolts that are holding on the bumper. There are two on each side.
3. Pull the bumper forward slightly and disconnect the stock fog lights.
4. Place the bumper down and remove each of the fog lights. There are 4 philips head screws that hold in each fog light.
5. Install the new fog lights into the bumper with the 4 screws from the previous step. Repeat for the other side.
6. Slide the bumper on the Jeep and connect the fog lights to the wiring on the Jeep.
7. Reinstall the 4 bolts that hold on the bumper.
8. Reinstall the upper splash shield.
9. Test the new LED lights.