



8748TS-MC Turn Signals Installation Instructions

Product Overview:

Huge light output in a small package. Features amber turn signal in a small form factor. They are an extremely bright and noticeable safety upgrade. Increase safety by illuminating your motorcycle to distracted drivers with the bright amber LED turn signal.

Typical Installation

Normal installation requires only a few tools, takes less than 45 minutes and requires no wiring on most installations.

Installation Warning

If you feel uncomfortable installing this product, we recommend having a professional complete the installation. Eagle Lights LLC is not liable for any damage to the product or vehicle due to an improper installation.

If you have questions about the installation, please feel free to call us at 1-800-921-3162 or email us at Support@EagleLights.com.

Installation:

Below are steps for typical installations on most Harley Davidson models. Steps may be different depending on the model and year of your motorcycle. Please ensure you have read through the instructions and understand them clearly before attempting the installation.

 WARNING! 
<ul style="list-style-type: none">• To prevent possible electrical shock, disconnect the negative battery terminal before installing this product.

- The SLIMLINE turn signals are a two wire LED turn signal. They do not have a running light, offering a clean look.
- To wire in the turn signals, locate the wiring for the turn signal on your Harley Davidson.

2

- Typically, the wiring colors will be black, blue, brown (right side) or black, blue, purple (left side).
 - For the right side:
 - Black connects to the black
 - Brown connects to the red
 - Blue gets capped off and is not used.
 - For the left side:
 - Black connects to black
 - Purple connects to red
 - Blue gets capped off and is not used.
- Test the turn signal functions.
- These lights themselves get mounted to the underside of the handlebars on the mirror ends using the stock hardware.