

8900B-BKO Installation Instructions

Installation:

Steps may be different depending on the model. Please ensure you have read through the instructions and understand them clearly before attempting the installation.

WARNING!

- To prevent possible electrical shock, disconnect the negative battery terminal before installing this product.
- Park the bike on a level surface. Allow the bike to cool before starting installation.
- Disconnect the negative battery terminal.
- Disconnect the headlight from the bike. You will be looking for a 4 pin harness that looks like the harness coming from the new light.
- Remove the old headlight. Refer to the owner's manual if you are unsure of this process.
- Keep the hardware, it will be used to reinstall the original light.
- After disconnecting the headlight, remove the assembly for the stock headlight. Remove and place to the side.
- Using the hardware from the original headlight, mount the new LED headlight to the bike.
- Connect the headlight to the bike.

- Reconnect the negative battery terminal.
- Test the high and low beam functionality of the headlight.