



8900TL-STG Installation Instructions

Typical Installation


Normal installation requires only a few tools, takes less than 35 minutes. No cutting or splicing is necessary to complete the install.

Installation Warning

If you feel uncomfortable installing this product, we recommend having a professional complete the installation. Eagle Lights LLC is not liable for any damage to the product or vehicle due to an improper installation. If you have questions about the installation, please feel free to call us at 1-800-921-3162 or email us at Support@EagleLights.com.

Installation:

Below are steps for a typical installation on most Harley Davidson models. Steps may be different depending on the model. Please ensure you have read through the instructions and understand them clearly before attempting the installation.

| |
|---|
|  WARNING!  |
| <ul style="list-style-type: none">• To prevent possible electrical shock, disconnect the negative battery terminal before installing this product. |

1. Begin with the motorcycle on a flat / hard surface. Remove the main fuse.
2. Remove Passenger backrest pad from the Tour Pak.
3. Remove the main seat to be able to access the battery.
4. Disconnect the rear lighting harness from the existing harness. Add the Y-Adapter in line between the two plugs you just disconnected.
5. Plug the light into the plug on the Y-Adapter
6. Reinstall the main fuse and test the function of the light.
7. Using warm water and a lint free rag, remove all dirt and debris from the install area.
8. Use the provided alcohol pad to clean the area. Let it dry completely.
9. Test the fitment of the light. Use masking tape to make alignment marks.

2

10. Remove adhesive backing. Press into place for 1 minute. It takes 24 hours for the bonding to completely cure. *If you are going to use the motorcycle before it is fully cured, use masking tape to keep it secure on the motorcycle.*
11. Locate provided Cable Tie Mount and Cable Tie. On the bottom portion of the Tour-Pak, along the edge of the passenger's left (clutch) side speaker, align and place the mount. Insert the cable tie through the mount. Place the lid light cord on top of the mount, in between each open end of the cable tie. Loosely fasten the cable tie around the wire.
12. Locate provided four (4) Cord Keepers. Test fit several locations along the front of the Tour-Pak for the Cord Keepers. Use masking tape to make alignment marks.
13. Open the Tour-Pak to determine that the wire has enough slack to allow it to open and close properly. Once satisfied with wire slack and positioning, tighten the cable tie
14. Reinstall the seat and backrest.