



FTSR Installation Instructions

Installation:

Steps may be different depending on the model. Please ensure you have read through the instructions and understand them clearly before attempting the installation.

WARNING!

- To prevent possible electrical shock, disconnect the negative battery terminal before installing this product.

- Wiring the FTSR:
 - The installation is fairly simple on most models. Use the below color codes to connect the tail light to the wiring on your motorcycle.
 - Black - Ground
 - Red - Brake Light Positive
 - White - Running Light Positive
 - Yellow - Turn Signal Positive(Wire Side)
 - Green - Turn Signal Positive
 - Connect each wire to to the corresponding function on the motorcycle.
 - If your motorcycle's turn signals also function as brake light function, you will need to wire the turn signal wires (Green and Yellow) to the front turn signal positive wiring.
 - Use the included Eagle Tap wires to connect the wiring.
 - Unscrew the top portion and thread the wire through.

2

- Unscrew the other side and place it over the wire.
- Slowly screw on the tops to make the connection.