



SFD1 Installation Instructions

Installation Warning

If you feel uncomfortable installing this product, we recommend having a professional complete the installation. Eagle Lights LLC is not liable for any damage to the product or vehicle due to an improper installation. If you have questions about the installation, please feel free to call us at 1-800-921-3162 or email us at Support@EagleLights.com.

Installation

▲**WARNING!**

- To prevent possible electrical shock, disconnect the negative battery terminal before installing this product. Remove the main fuse if applicable. Park the bike on a level surface.

1. The installation is fairly simple. The diodes will need to be wired into each positive wire going to the indicator bulb. See figure 1.
2. Cut the two positive wires going to the turn signal indicator.
3. Strip back the wires on either end. Place the heatshrink over one of the wires.
4. Solder the diode to each end. Ensure the silver line is toward the indicator light.
5. Move heatshrink over the diode.
6. Using a heatgun or lighter, apply heat to the heat shrink.
7. Reconnect negative of battery terminal.
8. Test turn signals.

Figure 1:

