

planks®

PEEL AND STICK WOOD-LOOK WALL PLANKS

1) WALL + PLANK PREPARATION

Be sure to let the PLANKS acclimate for 48 hours prior to installation and make sure your wall surface is clean, dust-free, smooth, flat and structurally sound. Clean the surface to remove any dirt and dust that might impair adhesion. **FOR PROPER ADHESION, BE SURE TO PRIMER THE ENTIRE WALL SURFACE WITH A MULTI-PURPOSE PRIMER.** Be sure to follow manufacturer's suggested dry time prior to installing PLANKS. **PLANKS CANNOT BE INSTALLED ON TEXTURED SURFACE WALLS.**

2) WHAT TO EXPECT

The medleys are pre-mixed upon arrival but we suggest even a more random placement avoiding the same finish side-by-side. We also suggest random sizes to start each row while intermingling the remaining portion randomly into the installation.

PLANKS are flexible, contour to curves or wall fluctuations and are suitable for use in high moisture environments like bathrooms and kitchens. They are also antimicrobial, waterproof and can be cleaned with a wide variety of household cleaners. PLANKS are great for potentially high traffic areas as well, thanks to highly durable and protective surface.

Planks **should not be** installed in showers, outdoors or exposed to excessive radiant heat or open flames.

3) ADHERING THE PLANKS

We suggest planning the installation well prior to placing any PLANKS and creating a level guideline to work off of.

When ready to apply, remove adhesive backer just prior to installing paying careful attention to not touching the adhesive.

Align edge along your guideline or adjacent row keeping the PLANKS at an angle to avoid sticking to the wall until ready. Adjust as necessary. Gently press to the wall initially. Check the position one more time and when satisfied apply firm pressure across the surface of the PLANK with a J-Roller to permanently set the PLANKS. Be sure to roll the entire surface of the PLANK so all adhesive has good contact with your wall. Note: The adhesive is pressure-sensitive meaning initial pressure is very important.

BE SURE TO PRESS THE ENTIRE SURFACE OF THE PLANK WITH FIRM PRESSURE WITH A J-ROLLER TO PERMANENTLY ADHERE.

When you come to the end of a row you will need to measure and cut the final piece. Once you have installed the cut piece the remainder can be used to start the next row or intermingled into the installation elsewhere. Avoid continually using the remaining piece from the end of the row to start the next row or you will create a stair-stepping effect. Remember the more random the final product appears the better it will look.

We fully understand each installation will come with a unique set of potential challenges so please feel free to reach out to us with questions or concerns.

4) CUTTING THE PLANKS

For most installations all you really need is a utility knife, straight edge and a suitable and safe cutting surface. You can score the PLANK from the front, bend and snap, and cut the tape on the back to free it up. That's all there is to it. Of course, if you are handy and have power tools you can use those as well.

PEEL. STICK. WOW.

inhabit®
surround yourself

1-888-830-5072 inhabitoliving.com