

planks®

PEEL AND STICK WOOD-LOOK WALL PLANKS

PEEL AND STICK INSTALLATION INSTRUCTIONS

1) WALL + PLANK PREPARATION

Let the PLANKS acclimate for 48 hours prior to installation. Wall surface must be clean, dust-free, smooth, flat and structurally sound. Clean the surface to remove any dirt and dust that might impair adhesion. **FOR PROPER ADHESION, BE SURE TO PRIMER THE ENTIRE WALL SURFACE WITH A MULTI-PURPOSE BONDING PRIMER. Note: Do not use a paint/primer combo product in place of the bonding primer.** Follow manufacturer's suggested dry time prior to installing PLANKS. **PLANKS CANNOT BE INSTALLED ON TEXTURED SURFACE WALLS.**

2) WHAT TO EXPECT

Medleys are pre-mixed upon arrival but we suggest even more random placement to avoid the same finishes side-by-side. We also suggest random sizes to start each row while intermingling the remaining portion into the installation.

PLANKS are flexible, contour to curves or wall fluctuations and are suitable for use in high moisture environments like bathrooms and kitchens. They are also antimicrobial, waterproof and can be cleaned with a wide variety of household cleaners. PLANKS are great for potentially high traffic areas as well.

Planks **should not be** installed in showers, outdoors or exposed to excessive radiant heat or open flames.

3) ADHERING THE PLANKS

We suggest planning the installation well prior to placing any PLANKS and creating a level guideline to work off of.

When ready to apply, remove adhesive backer just prior to installing paying careful attention to not touching the adhesive.

Align edges along guideline or adjacent row keeping the PLANKS at an angle to avoid sticking to the wall until ready. Adjust as necessary. Gently press to the wall initially. Check the position one more time and when satisfied apply firm pressure across the surface of the PLANK with a J-Roller to permanently set the PLANKS. Roll the entire surface of the PLANK to ensure all adhesive has proper contact with your wall. **Note: The adhesive is pressure-sensitive meaning pressure at installation is very important.**

BE SURE TO FIRMLY PRESS THE ENTIRE SURFACE OF THE PLANK WITH A J-ROLLER TO PERMANENTLY ADHERE.

When coming to the end of a row measure and cut the final piece. Once the cut piece is installed the scrap piece can be used to start the next row or intermingled elsewhere. Avoid continually using the remaining piece from the end of the row to start the next row or a stair-stepping effect will be created. The more random the final product appears the more natural it will look.

We fully understand each installation will come with a unique set of potential challenges so please feel free to reach out to us with questions or concerns.

4) CUTTING THE PLANKS

For most installations a utility knife, straight edge and a suitable and safe cutting surface are all that is needed. Score the PLANK from the front, bend, snap and cut the tape to free it up. That's all there is to it. Power tools can be used as well in place of tools listed above.

PEEL. STICK. WOW.

inhabit®
surround yourself

1-888-830-5072 inhabitoliving.com