

Rain Bird Repair Parts

Rain Bird backflow assemblies were private labeled by Watts for Rain Bird so replacement parts are available through Watts the following guide can help you in selecting the right Watts model.

Model	Sizes	Watts Equivalent
DC	$\frac{3}{4}$ " , 1" , 1 $\frac{1}{2}$ " , 2" , 2 $\frac{1}{2}$ " , 3" , 4"	Model 700
DCQT	$\frac{3}{4}$ " , 1" , 1 $\frac{1}{2}$ " , 2"	Model 007 or 007M1
<p>Note the $\frac{3}{4}$" and 1" model if it is a 007 version should have a round thread on cover. The 007M1 version would have a four bolt square cover. The difference for the checks was a change from a bronze poppet to a plastic poppet.</p>		
DCA	$\frac{3}{4}$ " , 1" , 1 $\frac{1}{2}$ " , 2" , 2 $\frac{1}{2}$ " , 3" , 4" , 6" , 8" , 10"	Model 709
<p>Note the $\frac{3}{4}$" – 2" sizes have two square covers with four bolts each. One for each check. Number one on top and number two on bottom.</p>		
RP	$\frac{3}{4}$ " , 1" , 1 $\frac{1}{4}$ " , 1 $\frac{1}{2}$ " , 2" , 2 $\frac{1}{2}$ " , 3" , 4" , 6"	Model 900
RPQT	$\frac{3}{4}$ " , 1" , 1 $\frac{1}{4}$ " , 1 $\frac{1}{2}$ " , 2"	Model 009 or 009M1
<p>Note there is not a 009M1 in $\frac{3}{4}$" and 1" sizes. M1 version effected the 1 $\frac{1}{4}$" – 2" sizes. The poppet assemblies are brass in the 009 and plastic in the 009M1 as well as a visual difference in the seat on the #1 check assembly, but no visual difference in the #2 check seat but they do have different part numbers.</p>		
RPA	$\frac{3}{4}$ " , 1" , 1 $\frac{1}{4}$ " , 1 $\frac{1}{2}$ " , 2" , 2 $\frac{1}{2}$ " , 3" , 4" , 6" , 8" , 10"	Model 909, or 909M1
PVB	$\frac{1}{2}$ " , $\frac{3}{4}$ " , 1" , 1 $\frac{1}{4}$ " , 1 $\frac{1}{2}$ " , 2"	Model 800