BRAINWAVZ[®]

CLAMP - ASSEMBLY GUIDE

Images in this guide are for illustration only - your product may differ from that shown

Attach the Clamp



Ensure the clamp () is pushed up as far as it can go, then place the bolt () into the clamp, and finger tighten so it remains in place



3 Use a flat head screwdriver **()** and turn the bolt **()** clockwise until you feel resistance - DO NOT OVER TIGHTEN



Apply Non-Slip Furniture Protection Pads

Install Bolt



Stick the felt pads (A) to the underside of the clamp (B)



Thread the bolt clockwise (right) into the hole on the bottom of the clamp



Attach Brace Plate

 Hold the clamp B and brace plate D with two hands and press down firmly to clip the plate onto the bolt O

Clamp on to Desk

4 Adjust the bolt so that it is just a little wider than the thickness of intended surface.

Slide the clamp onto the surface and turn the bolt o gently clockwise (right) until you feel a little resistance, then twist the bolt one more





Visit brainwavzaudio.com/collections/clamp-on-collection to see the full range.