

Included hardware:

Qty: 4, 5mm x .8mm x 20mm bolt

Qty: 4, 5mm x 15mm washers

Qty: 12, 5mm x .8mm flange nuts

Installation:

1 - The flanged end of the fin matches the shape of rear belly pan.

2 - The inner fins use the factory OE fastener.

3 - The fin studs mount through the rear factory screen mesh and fastened with the flange nuts

## C8 Diffuser Fin Orientation

