



1. Proceed with fan installation in accordance with fan instruction sheet S3655
2. Attach suspension hook (from this kit) firmly to a solid mounting plate. As illustrated, turn so that hooks face away from each other; for a 45 deg. tilt (fan with 24" downrod), distance between hooks should be approximately 28".
3. Apply pair of clamps over downrod, using 3 plain bolts as illustrated. Before tightening nuts, turn clamp to align with shackle.
4. Place both S-hooks as shown, slip last link of chain on S-hook (clamp end) and tilt fan to desired angle - do not exceed 45 deg. from vertical. Engage chain on upper S-hook and discard unused chain links.