

FX0150 PowerTrack Assembly Instructions



Package Contents:

- 1 x piece of PowerTrack
- 4 x End Caps
- 20 x Screws
- 10 x Washers

Tools Required:

- Safety glasses
- Drill with 1/8" bit
- Phillips Screwdriver
- Stud finder and small drill bit / finishing nail
- Tape Measure
- Marker / Pencil

Step 1: Check the parts received



Step 2: Locate and mark the ceiling joist locations

Step 3: Cut the PowerTrack to the desired length if necessary using a Jigsaw, Mitre Saw or Hacksaw

Step 4: Drill 1/8" holes at the determined joist locations, use the line inside the PowerTrack to centre the holes

Step 5: Screw into the ceiling joists. Use screws and washers if mounting directly onto an exposed joist or through a single thickness of drywall.

Step 6: Press the end caps into the channel ends

Notes:

1. Try to mount the channel perpendicular to the ceiling joists as this spreads the load
2. Screw into the ceiling at every joist location, preferably every 406mm
3. Always screw the ends of the PowerTrack into a joist, don't leave the end hanging
4. Always use the washer and screw