

FlexiTrack Assembly Instructions

These instructions are designed to help you install our FlexiTrack wall kit



Package Contents:

- Each length of FlexiTrack is 2460mm in length and comes with 10 white headed screws.

Tools Required:

- Electric screwdriver or drill with Phillips driver bit
- Stud finder (or small brad nails)
- Spirit level and pencil
- If you intend cutting the FlexiTrack into other lengths, we recommend using a mitre saw, table saw or circular saw
- Safety glasses

Step 1: Check that you have everything you need ready

Step 2: On the wall area where you wish to install your FlexiTrack, locate and mark the stud centrelines. To do this either use a stud finder or the traditional method of small brad nails. Alternatively, if fixing to a brick or block wall use wall plugs at 400mm centres.

Step 3: Decide at which height you are going to put the FlexiTrack and mark this out

Step 4: Using the stud locations found in step 2, insert the screws through the FlexiTrack and into the wall. You should use one screw in each of the grooves for stability and at each stud location.



Step 5: If you have purchased the End Caps, they simply slide on.

Tips:

- We recommend only installing FlexiTrack on bare studs or on brick/block walls
- Make sure that your two ends are fastened securely before adding storage accessories to it