

## FlexiTrack Assembly Instructions

These instructions are designed to help you install items FX10008-1, FX10008-11 and FX10008-43.



### Package Contents:

- FX10008-1 will have 1 x 2460mm length of FlexiTrack and 10 screws
- FX10008-11 will have 2 x 2460mm lengths of FlexiTrack and 20 screws
- FX10008-43 will have 8 x 2450mm lengths of FlexiTrack and 100 screws

### Tools Required:

- Electric screwdriver or drill with Phillips driver bit
- Stud finder (or small brad nails)
- Spirit level and pencil
- If you intend cutting the FlexiTrack into other lengths, we recommend using a mitre saw, table saw or circular saw
- Safety glasses

If you have any questions or need some advice, please do call us on 01491 579975 or email us at [info@garageflex.co.uk](mailto:info@garageflex.co.uk) and we will do our best to help.

Step 1: Check that you have everything you need ready

Step 2: On the wall area where you wish to install your FlexiTrack, locate and mark the stud centrelines. To do this either use a stud finder or the traditional method of small brad nails. Alternatively if fixing to a brick or block wall use wall plugs at 400mm centres.

Step 3: Decide at which height you are going to put the FlexiTrack and mark this out

Step 4: Using the stud locations found in step 2, insert the screws through the FlexiTrack and into the wall. You should use one screw in each of the grooves for stability and at each stud location.



Step 5: If you have purchased the End Caps, they simply slide on.

## Tips:

- We recommend only installing FlexiPanel on bare studs or on brick/block walls
- Make sure that your two ends are fastened securely.