



AMERICAN CAR CRAFT INSTRUCTIONS

C5 CORVETTE HOOD ACCENT KIT

PART#033006



PARTS INCLUDED:

- 1-Adhesive Promoter
- 3-Stainless Panels

ITEMS NEEDED:

- Household Clear Silicone
- Isopropyl Alcohol
- Household Lacquer Thinner

1. Remove the stock fiberglass heat shield.

NOTICE: 1" inch ridge forming the perimeter of the three sections where panels will be installed.

2. Thoroughly scrub area where panels will be installed with household Isopropyl alcohol. This will clean any dirt/residue that might affect the red attachment tape from sticking properly.
3. Apply adhesive promoter pads (provided) around the perimeter of three areas where hood panels will be installed.

NOTE: The promoter pads help the panels to stay adhered to surface. **IMPORTANT:** Pay close attention to fit and shape of panels. It may be necessary to bend the panels a little in order to form a comfortable and unforced fit. Once satisfied with the fit of panels, you must prepare them for final installation.

4. Thoroughly clean the three hood panel areas with Isopropyl alcohol and then with household lacquer thinner.
5. Apply some household 100% clear silicone to marked areas on the panels. Be sure to apply enough silicone so that it will make contact with both the hood and panel.
6. Once enough silicone is applied, remove the red attachment tape and insert each panel and press firmly to set.

NOTE: Red attachment tape is used to hold panels in place long enough for silicone to cure, not to necessarily hold the panel. In fact, it is normal for some areas not to make contact at all. If you see some minor space between the panel and hood, don't panic. As long as the silicone is applied enough to make contact with both the hood and panel it will be fine.

7. Leave hood open overnight to allow silicone to set. Leaving hood open will allow silicone to set correctly.

Thank you and enjoy your purchase!

**If any questions occur during installation please contact
AMERICAN CAR CRAFT
18924 SAKERA ROAD-HUDSON FLORIDA 34667
Phone # 727-861-1500 Fax # 727-861-1520
www.americancarcraft.com**