



AMERICAN CAR CRAFT INSTRUCTIONS

C7 Side Skirts Stainless w\Fiberglass Overlay “Stingray” Style Part #052049



PARTS INCLUDED:

- 2-Stainless Steel with Carbon/Fiberglass Side Skirts
- 2-Packs of Adhesive Promoters

Liner info: Your new accessories will come to you with a protective surface liner. Leave this liner in place until the installation is complete to prevent finger prints and or possible scratches during installation. This liner is required to remain on the part until you are instructed to remove it.

1. Thoroughly scrub clean the bottom of the cars rocker with alcohol to remove and all road grime and dirt. Then swipe the area with the adhesive promoter provided. This chemical is not a cleaner but an adhesive accelerator and must be used as such in order to insure a good long lasting and permanent bond.
2. Remove all the screws securing the bottom of the rocker panel with the exception of the two slightly recessed screws at the front end of the rocker.
3. Using the help of a friend bring the side skirt into position so that you can get a good idea of how the skirt is intended to fit. Remove the protective liner completely and then peel back the red release liner at the two ends back and towards you just a couple of inches creating a sort of pull tab. Do not remove the liner completely.
4. Set the skirt up to the rocker and install all the screws removed earlier. Set these screws in by hand but do not tighten them just yet.
5. Once all the screws are in place bring the skirt up the rocket to set its position. The holes in the skirt are slightly oblong and will allow you to set the skirt so that the corner of the skirt does not protrude. Once you have a good position pull the red release liner from the attachment tape as you press the skirt to the rocker riding up over the screws. Press the skirt firmly to the rocker to set the bond. Then snug all the screws to finish the installation.

Thank you and enjoy your purchase!

If any questions occur during installation please contact

AMERICAN CAR CRAFT

18924 SAKERA ROAD-HUDSON FLORIDA 34667

Phone # 727-861-1500

Fax # 727-861-1520

www.americancarcraft.com