



# AMERICAN CAR CRAFT INSTRUCTIONS

## C7 GM Licensed 5pc Z06 Emblem Cap Set

Part #053093 Patent Pending



### **PARTS INCLUDED:**

- 1-Styrofoam Circle for oil cap
- 3-3/4" Caps (Brake Fluid Reservoir, Coolant Reservoir, & Oil Fill)
- 1-1/2" Cap (Windshield Washer Reservoir)
- 1-1" Cap (Power Steering Unit)
- 1-Pack of Adhesive Promoter

1. The first step for installation will be to thoroughly scrub the tops of each of the factory caps, the oil, coolant, washer fluid, brake fluid, and electric power steering unit (canister in front of brake master cylinder). Scrub them with alcohol to remove any surface contaminants then swipe the tops with the adhesive promoter provided.
2. You have been provided with 2" furry Velcro attachment cookies for each cap. Peel the release liner from the back of each cookie and firmly set them to the top of each factory cap.
3. The factory windshield washer fluid cap will need to be trimmed slightly for the new cover to sit nice and centered. To do this, simply snip the finger tab as well as the attachment strap off the cap with scissors.
4. Simply set them in place and you're done!

**Thank you and enjoy your purchase!**

**If any questions occur during installation, please contact**

**AMERICAN CAR CRAFT**

**18924 SAKERA ROAD-HUDSON FLORIDA 34667**

**Phone # 727-861-1500**

**Fax # 727-861-1520**

**[www.americancarcraft.com](http://www.americancarcraft.com)**