



AMERICAN CAR CRAFT INSTRUCTIONS

CAMARO HOOD PANEL BADGE (2010-2013 Factory Hood Panel Only)

PART #103068



PARTS INCLUDED:

- 1- Camaro Emblem
- 1-Adhesive Promoter

PROTECTIVE LINER INFORMATION: Your new accessories will come to you with a protective surface liner. Leave this liner in place until the installation is complete to prevent finger prints and/or possible scratches during installation.

1. Remove the factory hood panel (pad) by popping all the hood retainers off. Keep these fasteners; they will be re-used to re-install the hood panel.
2. Wipe the indented hood panel emblem with a cleaner to remove any kind of grease or dirt from the road.
3. Use the supplied adhesive promoter packet and wipe the indented hood panel emblem.
4. Now the emblem will have 8 tabs sticking out of the back of the part. (These tabs are very pointy so be careful while installing it so that you don't poke yourself) These tabs will push through the factory black hood pad and bend back onto the hood pad. Holding the emblem to the hood pad.

5. Pull the Red 3M tape backing off and stick the emblem to the hood pad while pushing the tabs through the factory hood pad. Be careful to align the emblem properly the first time. You will not be able to make adjustments. And bend the tabs flat onto the back of the factory hood pad.

OPTIONAL STEP: Use a large dab of silicone adhesive when re-installing the hood panel, between the hood panel and hood. This will secure the hood panel to the hood and keep it from any potential sagging.

6. Once the emblem has been completely installed on the hood panel, reinstall the hood panel with the factory fasteners.

If any questions or problems occur during installation, please contact American Car Craft at 727-861-1500.

Thank You and Enjoy Your Purchase!

AMERICAN CAR CRAFT
18924 SAKERA RD HUDSON FL 34667
Phone: 727 861-1500 Fax: 727 861-1520
www.americancarcraft.com