



AMERICAN CAR CRAFT INSTRUCTIONS

CHALLENGER SHOCK TOWER DOME COVERS

PART #153013_{patent pending}



PARTS INCLUDED:

2-Shock Tower Domes
2-Attachment Brackets

These covers are a simple overlay designed to upgrade the look of the factory dome covers.

1. Remove the factory dome covers if so equipped. You will notice three shock tower nuts. Remove these nuts and place the stainless attachment bracket over the bolts and then replace the three nuts and tighten.

2. The bracket you have just installed will not set exactly flat to the surface do to the surface shape however the bracket will do the trick after you make some adjustments. In all cases you will need to pry the outer tab up a little by forcing a flat blade screw driver under the bracket and raising the bracket tab up a little to allow the tab to work for the new cover. At this time simply adjust the tabs at both ends of the bracket so that they will allow the new cover to snap in place. This may take a couple of adjustment attempts before you get it just right. Once the tabs have been adjusted properly it will be a simple matter of snapping the new cover on or off as needed. NOTE: The new cover will have a notch cut from one side. This notch is to face the rear of the car and will allow the new covers to sit nice and secure into position.

If any questions occur during installation, please contact

American Car Craft at 727-861-1500.

Thank you and enjoy your new purchase!

Note: Care must be taken when cleaning your covers. It is a good idea to lightly dust your covers with a clean soft cloth first in order to prevent any particles from scratching them. Then wipe (using a new clean soft cloth) with a good quality streak free glass cleaner.

AMERICAN CAR CRAFT

18924 SAKERA ROAD-HUDSON FLORIDA 34667

Phone # 727-861-1500 Fax # 727-861-1520

www.americancarcraft.com