



# AMERICAN CAR CRAFT INSTRUCTIONS

---

*1997-2002 Prowler Chrome Fluid Cap Cover*

**PART #823021**



**Parts Included:**

- 1-Chrome Cap Cover
- 1-Velcro Attachment Cookie
- 1-Adhesive Promoter

**Introduction:**

1. Place the main cap over the vent hat on the factory fluid cap allowing the vent cap to protrude through the hole atop the cap.
2. You have been provided with a small chrome decorative cap that contains butyl putty under this cap cover. Remove the paper liner from the butyl and simply press it onto the vent hat. This will attach the cap to the vent hat in such a way that it will allow you to remove and replace the fluid cap by detaching the chrome cap along with the plastic vent hat to release the main cap. To replace the cap simply set it place and then snap the chrome cap and vent hat assembly into the vent hat base.

**If any questions or problems occur during installation, please contact American Car Craft at 727-861-1500.**

**Thank You and Enjoy Your Purchase!**

**AMERICAN CAR CRAFT**  
**18924 SAKERA RD HUDSON FL 34667**  
**Phone: 727 861-1500      Fax: 727 861-1520**  
[www.americancarcraft.com](http://www.americancarcraft.com)