The Under Braider-Braiding.

Raise the needle and fit the quilter foot, as shown. To attach the under braider, insert the downwardly projecting hook of the attachment into the



hole in the throat plate at the right of the feed dog. Then place the guide thumb screw in the slot of the attachment and into the hole in the bed plate of the machine. The under braider must be firmly secured by tightening the screw.

The pattern or design to be braided must be stamped or traced on the wrong side of the material. Pass the braid from the left between the blued guide and the lower plate until it enters the back and front braid guides, and then under the needle. Place the material, wrong side up, above the braid, lower the presser foot and proceed to sew, following the lines of the design.

www.Singer-Featherweight.com

How to Perforate Braiding Designs.

Instead of stamping or tracing the pattern on the material itself, a perforated paper design may be used.



Braiding designs may be copied with the sewing machine by taking several thicknesses of paper and pinning them to the design you desire to copy, as shown above.

Attach the foot of the quilter to the machine and, without threading the machine, follow the design with the needle. Several copies of the design can be made in this way, one of which can then be pinned to the material to be braided and torn away when the braiding is finished.

www.Singer-Featherweight.com