



Assembly Instructions

Material Needed

Testers Flat White for Mortor Joints

Testers Dull Cote Spray Paint

Testers Flat (Choice of Colors) for doors, windows and trim.

Super Glue

1. Custom Painting. Remove all flash with file or emery board before painting. To fill mortor joints with white spray wall sections with white paint, wipe off excess with linen cloth until all paint is removed from surface except paint in mortor joints. To remove haze from brick surface apply a thin coat of Testers dull cote and wipe gently with clean linen cloth until surface is clean. Repeat throughout.
2. Paint all windows (choice of color) and when dry glue in place throughout.
3. To assemble building walls look at wall location sketch. Some slight sanding may be necessary. To glue wall sections together make sure they are square - line up walls properly and tack with super glue, bottom, center and top - use glue sparingly. Now apply a bead of glue on inside corner of wall section - repeat same throughout.
4. Glue in place wood roof support location shown on sketch and glue roof in place.
5. Bend downspouts according to sketch and glue in place, one on each position shown on sketch, over corner joint.
6. Glue in place loading dock as shown on sketch.
7. Glue in place all smokestacks and signs.
8. Touch up all paint where necessary when all super glue is dry. Dull Cote entire building. To add interest to your building, add your own personal touch with accessories.