



CONE 6

Technique was achieved by brushing on two (2) layers of base glaze. Then apply two (2) layers of top glaze (SW-175 Rusted Iron), letting glazes dry between coats.





You Tube

P





Rusted Iron

CONE 10

Technique was achieved by brushing on two (2) layers of base glaze. Then apply two (2) layers of top glaze (SW-175 Rusted Iron), letting glazes dry between coats.

> You Tube

O

P



Vases shown are fired to Cone 10 on White Stoneware body.

www.MaycoColors.com

