



How to use Clear Glazes

Clear Brush-On Glazes

IN1001 Envision Clear Glaze

1. Mix well.
 2. Apply 2 coats to shelf cone 04 bisque.
 3. Fire to shelf cone 06.
- Water cleanup.

SN351 Satin Clear Glaze

1. Mix well.
 2. Apply 2 coats to shelf cone 04 bisque.
 3. Fire to shelf cone 06.
- Water cleanup.

Clear Dipping Glazes

Dipping Instructions apply to the following products:

CN2000D Concepts Clear Dipping Glaze

GL612D Diamond Clear Dipping Glaze

SN351D Satin Clear Dipping Glaze

1. Initially mix with electric mixer. Mix daily with wire whisk.
2. Wear protective gloves. Submerge TL 497 Viscosity Cup into glaze. Lift from glaze. Begin timing (stop timing when a steady stream of glaze begins to break - 18-23 seconds is normal). If above 23 seconds, mix in small amounts of water as needed.
3. Using gloved hands or dipping tongs, rapidly submerge ware into glaze, covering as much area as possible. Quickly lift ware out of glaze, giving ware a slight shake to minimize excess drips or runs. Let dry.
4. If necessary, dip unglazed portion, slightly overlapping glazed area for full coverage. Let dry.
5. Use a SB 807 Fan Glaze Brush to glaze any missed areas. Use TL 420 Palette Knife to shave off drips or runs to prevent airborne dust.
6. Stilt and fire to shelf cone 06.