

Mayco Stoneware Dry (SD) Mixing Instructions

Always wear a NIOSH approved respirator when handling dry glazes.

Gently tumble the unopened bag to redistribute materials. Sieving is not necessary.

Mix one 10 lb bag of dry material into at least 10 pints of water. Stir thoroughly.

Add additional water until desired specific gravity is reached. Specific gravity preference will vary between studios, persons, and practices.

Our recommended specific gravity is in the range of 1.47-1.51. This is for a 1 second dip time, you may want to mix to a lower specific gravity if you layer glazes or tend to dip longer.

Stir well before use. Immerse the ware for 1-2 seconds. Allow the glaze to dry before applying additional coats if desired.

When applying Stoneware Dry Crystal glazes, use a cup or ladle to pour the glaze over your piece. While the glaze is wet, you may use a fan brush to evenly distribute the crystals; avoid heavy crystal loading on the bottom third of your piece.

Fire to preferred temperature, cone 5-10 (2167F-2345F / 1186C-1285C). Testing is recommended. The choice of clay body, thickness of application, firing process and temperature will affect the fired results.