

The A1 and A2 measurements need to match the physical product. If these measurements are proving challenging to achieve within a lesser tolerance, perhaps an ellipse hole would overcome the challenge and ensure install is made easier?

Recommendation.

Start by deciding which orientation your PM02 is facing. For example, connector holders facing users or facing away. Measure how far away from wall you want the PM02. We recommend at least 300mm to allow for use of connectors and servicing of charge points.