

Instructions for installing the 132.07 Palette Extension Kit



- Find the two pre-drilled holes inside the right side of the box. They will be quite small, and they might have gotten filled in with a bit of sawdust. You can enlarge them with a nail if you like.
- Use two of the three screws provided to attach the hinge. The hinge will sit just above the edge of the side of the box so that it will lay flat when open. We provide an extra screw in case one gets lost.
- Make sure the corner “stop” is facing up and the brush-holes are toward the back.
- Do not over-tighten the screws.