

WOZ Castle Walls Installation

- 1 Pull the playfield and set in in a resting position



- 2 Remove all the existing wall sections (3pcs)

- The 2 pieces over the doorways are held on with plastic rivets and can be easily removed by pulling them apart with your fingertips or a small needle nose pliers. The other 2 pieces are simply held on by wood screws and can be removed with a small Phillips screw driver.

- 3 Let's start by installing the main piece (# 3 and # 4) which are attached with the main bracket:

- The 2 screws coming out of the back of the bracket have two machine nuts on it - remove one nut on each screw and set aside

- Carefully install the two piece doorway set by pushing the screws through the two existing brackets that held up the old walls

- Take the two nuts that were set aside and tighten down those two screws, secure tightly with needle nose pliers (make any adjustments with the flexible bracket to insure that it is straight over the doorway and maintains clearance of the swinging door by the winged monkey)



- 4 Install angled bracket (provided) by removing the existing nut # 3

WOZ Castle Walls Installation



Angled bracket
attached to 3rd
existing screw

- 5 Install L bracket (provided) by removing the existing nut # 5 (spot light)



L bracket attached
to 5th existing
(spot light) screw

- 6 Now, install wall piece # 2 to carefully fit notched out areas over the existing nuts on the brackets that are tightened down



wood screws

WOZ Castle Walls Installation

- Use the small 1/2" screw (provided) and attach on the left side using the metal flap from the main bracket. This piece should fit snugly and pushed down when screwing together

- Now, use wall piece # 1 and line up the top edges and use the wood screw (provided) to attach to playfield side and use 1/2" small screws to screw together wall pieces at the top of the L bracket.

- Some adjustments may be required to fit evenly, the pieces are somewhat flexible and can be positioned properly if you take the time.

- 7 Lastly, the large wall piece # 5 is simply screwed into position using the wood screws (provided). **Tip:** after removing the original wall, put back the small screws it was held with half way, than, take the new wall piece and push against those screws, use the new 1" screws from the back side of the wall piece until they pertrude through the front. This will allow you to line up the holes exactly with the playfield. **Install the witch's cage (if ordered) prior to installing piece # 5.**

- Check for all clearances prior to any game play to insure nothing gets in the way, these wall pieces are very durable and should last for the life of your game.

If you have any questions or problems contact me personally through Pinside

The Modfather

Contents:

