



50/50

OVER/UNDER DOME

For Use With
GoPro® HERO9 Black Camera



What's Included

FiftyFifty

Dome | Defender^{H2O} | Dome Port Plug

GoPro Installation

Step 1

Place GoPro lens into dome. Flip the latch over the back of the GoPro and press the clamp down.

Step 2

Double-check the latch is secure before continuing.

Step 3

Uninstall Defender^{H2O}.

Step 4

Ensure all dome clamps are free from sand/debris and locked securely in place to prevent leakage.

Cleaning After Use and Storage

Step 1

Rinse with fresh water thoroughly prior to removing the GoPro.

Step 2

Dry dome with a debris-free cloth.

Step 3

Cover dome with Defender^{H2O}.

Step 4

Release clamp and remove latch to remove GoPro.

Step 5

Install the included plug to prevent dust from entering the dome during storage.

Removing/Replacing Lens

Step 1

Unclip clamps around the outside of the dome.

Step 2

Remove lens. Make sure to keep the rubber o-ring for future secure sealing.

Step 3

Once dry, ensure rubber o-ring is in place and even.

Step 4

Release clamp and remove latch to remove GoPro.

Step 5

Place lens on dome.

Step 6

Secure top clamp and then continue to secure the four other clamps one by one ensuring that the rubber o-ring is even.

More Info

Tutorials

For additional help be sure to visit our YouTube page:

[youtube.com/polarprofilters](https://www.youtube.com/polarprofilters)

for tutorials and more.

Questions

Contact us at anytime via our website, or shoot us an email. We're happy to help.

polarpro.com | 949.220.9395

support@polarpro.com