



SHUTTER COLLECTION

Shutter Collection
GoPro HERO9

VERSION 1.0



What's Included

Shutter 3-Pack [H9-1016]

ND8 | ND16 | ND32 | *Minimalistic Hard Case*

Installation Process

Step 1

First, uninstall the stock UV by pulling up and twisting the frame counter-clockwise.

Step 2

Next, to install the ND filter, place the filter 45 degrees counterclockwise and ensure the frame is flush against the body of the GoPro.

Step 3

Push down and rotate clockwise until the filter is squarely aligned to the lens, without deviating to one side.

Installation Process (Continued)

Step 4

To ensure it is installed correctly, the filter should not be able to be pulled off and the etching for the ND should be centered directly above the lens.

Still unsure about your HERO9 Shutter Collection installation, check out the getting started video located on our YouTube Channel or FAQ page.

GETTING STARTED VIDEO

More Info

Tutorials

For additional help be sure to visit our YouTube page:

[youtube.com/polarprofilters](https://www.youtube.com/polarprofilters)

for tutorials and more.

Questions

Contact us at anytime via our website, or shoot us an email. We're happy to help.

polarpro.com | 949.220.9395

support@polarpro.com