



What's Included

Combo sets and single filters.

Directors Collection | Edition 1 [MVC3-DRCT-CLLTN-ED1]

VND2-5 | VND6-9 | Mist [1/4] | BlueMorphic | GoldMorphic | CP | ND8PL | ND16PL | ND32PL | Edition 1 Case

Directors Collection [MVC3-DRCT-CLLTN]

VND2-5 | VND6-9 | Mist [1/4] | BlueMorphic | GoldMorphic | CP | ND8PL | ND16PL | ND32PL | Storage Case

Cinema Kit [MVC3-CINEMA]

VND2-5 | VND6-9 | VND2-5 Mist [1/4] | VND2-5 BlueMorphic | VND2-5 GoldMorphic | Storage Cases

Vivid Collection [MVC3-VIVID]

ND8PL | ND16PL | ND32PL | Storage Case

FX 3-Pack [MVC3-FX-3PK]

BlueMorphic | GoldMorphic | Mist [1/4] | Storage Case

VND 2-Pack [MVC3-VND-2PACK]

VND2-5 | VND6-9 | Storage Case

Single Filters [CP / VND2-5 Mist [1/4] / VND2-5 BlueMorphic / VND2-5 GoldMorphic]

Filter | Storage Case

Filter Installation

Attaching filters to the drone camera.

INSTALLATION_

Step 1:

Filter installation must be done prior to powering on the drone*

Step 2:

Support the gimbal in one hand. Using your other hand, press gently and turn the stock UV counter-clockwise and remove.

Step 3:

Align the filter tabs with the corresponding lens slots on the Mavic 3 camera. When seated flush to the lens, press lightly and turn clockwise until the filter clicks into place.

REMOVAL_

Step 1:

Follow steps 2 and 3 above to replace the stock UV or change filters.

More Info

Questions and support.

QUESTIONS?

Reach out any time via live-chat on our website, or shoot us an email. We're happy to help!

polarpro.com | support@polarpro.com | 949.220.9395