

FOR FRONT STOCK BUMPER

GEN 2 (2017-2020)

Step 1:

Remove plastic front cover to access bumper bolts and adaptive cruise control module, if equipped.



This can be done
With a plastic pry
tool and gently
prying out on the
plastic cover at the
spots where the
clips are as pictured.





FOR FRONT STOCK BUMPER

GEN 2 (2017-2020)

Step 2: If you don't have adaptive cruise control, skip this step.

Remove the adaptive cruise control module.

This is done by removing the one nut and then gently pulling the module off the adjuster balls.



Then unplug the module, set aside for reassembly






FOR FRONT STOCK BUMPER


GEN 2 (2017-2020)

Step 3:

On the backside of the bumper, there is a bumper support strut.



Unbolt this from the bumper on both driver and passenger sides





FOR FRONT STOCK BUMPER

GEN 2 (2017-2020)

Step 4:

Now the main bumper bolts can be removed along with the bumper.

We recommend a second pair of hands to help with this. Remove one nut on the back side of the front bumper on the outside of the frame rail





Then remove the two nuts on the front of the bumper on each side.








FOR FRONT STOCK BUMPER


GEN 2 (2017-2020)

Step 5:

With the bumper off and set on a bench or the ground, the light bar mount can now be installed to the bumper.

5A: Start by removing the two pictured bolts on each side of the bumper.





The **bolts won't** be reused,
But the two **supplied spacers**per side **will** be used.






FOR FRONT STOCK BUMPER

GEN 2 (2017-2020)

Step 5 (cont.)

5B:

The light bar mount can now be installed with the supplied longer bolts. The tab on the light bar mount goes behind the bumper support, but doesn't get bolted up, it is there as an additional support.





FOR FRONT STOCK BUMPER

GEN 2 (2017-2020)

Step 6:

Reinstall the bumper in reverse order of how it was removed.

When bolting the bumper back up a second pair of hands is again recommended, and before tightening all the bolts, align all body gaps to your liking, then tighten all bolts to factory spec.