



LOWER REAR SHOCK SKID KIT

INSTALL

RAM TRX (2021 - 2022)

Step 1:

Park vehicle on level ground, set the parking brake.
Block the front tires front and rear so the truck can't roll.



Step 2:

Place a jack under the rear differential and lift the truck high enough that jack stands can be placed under the frame rails so that the rear suspension can hang freely without touching the ground.



Alternatively, you can lift the truck off of the hitch until the rear tires come off the ground, then support the vehicle with stands.

DO NOT work under an unsupported vehicle.



LOWER REAR SHOCK SKID KIT

INSTALL

RAM TRX (2021 - 2022)

Step 3:

Starting on the passenger side, remove lower shock bolts and discard bolt, but save the nut - the nut will be reused on the new supplied bolt.

Step 4:

Hold the shock skid over the lower shock mount, install the lower shock bolt to hold the skid onto the mount, and then hold the skid flush to the back side of the shock mount. Next install the supplied $\frac{3}{8}$ " bolt, washers and nylock nut through the slotted hole on the shock mount and tighten. Install the bolt from the outside of the shock skid inward, so that the nut is on the inside of the lower shock mount.

Step 5:

Reinstall the rear shock into the lower shock mount, you may need a jack or a friend to move the axle up or down for the shock to line up with the shock mounts. Once the shock is installed, tighten all hardware to factory spec.





LOWER REAR SHOCK SKID KIT

INSTALL

RAM TRX (2021 - 2022)

Step 6:

Repeat steps 3-7 for the drivers side.

Step 7:

Lift the truck off the stands, set it back on the ground, and remove the front wheel blocks.