

# Pre-pasted

## WALLPAPER INSTRUCTIONS

### STEP 1: SURFACE PREPARATION

To ensure your *anewall* adhesive sticks to the surface, make sure it is smooth, clean, and dry. Walls must be smooth before installation. Give your surface a brief wipe down with a clean, dry cloth. For best results, priming your wall with a universal primer is recommended, but optional.

### STEP 2: PLANNING YOUR LAYOUT

The panels included in your package are numbered on the back and must be installed in chronological order from left to right in order to achieve the final mural design. Please lay out all panels before beginning your installation.

Mark your wall for positioning of Panel 1. For ease of installation, leave a 2" bleed of excess on the left side. To ensure straightness of your mural, use a level to mark the end of Panel 1.

### STEP 3: ACTIVATING THE GLUE

Loosely roll the first panel with the printed side facing inwards. Roll a generous amount of water onto the back of the panels to activate the glue. Book the wallpaper by folding each ends of the panels towards the middle, pasted sides together. This ensures the edges do not dry out. Leave it like this for 10 minutes. The product will expand slightly during this time.

MATERIALS NEEDED: Clean dry cloth, paint roller, measuring tape, level, straight edge ruler, Exacto knife, plastic scraper or squeegee, wallpaper tray, seam roller, water, and a sponge.

### STEP 4: INSTALL FIRST PANEL

Leave a slight 2" bleed overhang at the top of the first panel to begin installation. This will avoid any gapping due to slanting and uneven walls and ceilings.

Use a plastic scraper, squeegee, or damp sponge to smooth out the panel onto the wall. Unbook the wallpaper as you go. Finish off by securing the seams using a seam roller and trim excess wallpaper.

### STEP 5: REPEAT STEPS 3 TO 4

Place the next panels to the edge of the previous panel. Panel seams should be vertical and have a tight fit.