

Adhesive Vinyl

WALLPAPER INSTRUCTIONS

STEP 1: SURFACE PREPARATION

To ensure your *anewall* adhesive sticks to the surface, make sure it is smooth, clean, and dry. Walls must be smooth before installation. Give your surface a brief wipe down with a clean, dry cloth. For best results, priming your wall with a universal primer is recommended, but optional.

STEP 2: PLANNING YOUR LAYOUT

The panels included in your package are numbered on the back and must be installed in chronological order from left to right in order to achieve the final mural design. Please lay out all panels before beginning your installation.

Mark your wall for positioning of Panel 1. For ease of installation, leave a 2" bleed of excess on the left side. To ensure straightness of your mural, use a level to mark the end of Panel 1.

STEP 3: INSTALL FIRST PANEL

Peel back 2" of the lining and trim. Leave a slight 2" bleed overhang at the top of the first panel to begin installation. This will avoid any gapping due to slanting and uneven walls and ceilings.

Use a plastic scraper or squeegee to smooth out the panel onto the wall. Remove the lining as you go. Finish off by securing the seams using a seam roller and trim excess wallpaper.

MATERIALS NEEDED: Clean dry cloth, measuring tape, level, straight edge ruler, Exacto knife, plastic scraper or squeegee, and a seam roller.

If bubbling begins to occur once the panel is installed, poke the bubble with a needle or Exacto knife and smooth it out with your scraper or squeegee.

STEP 4: INSTALL SECOND PANEL

It is important to note that 2" of the second panel will overlap the first panel. The overlap will help you line up the design easily and aid in keeping the second panel level. Install the second panel by following Step 3, while keeping the overlap in mind. Review the image before you move on to do any cutting.

STEP 5: REPEAT FOR REMAINING PANELS

Place the next panels with 2" overlap on the previous panel. Panel seams should be vertical.

**OPTIONAL STEP 6: CUTTING THE SEAM

If the seams between the panels are noticeable, take a straight edge ruler and an Exacto knife to slice through the two layers of the mural, 1" in from both edges of the overlap. Gently peel away the outer piece of excess material. Peel away the remaining excess material underneath the overlap. Smooth the panels back together and you should now have perfectly matched seams!