

**Mounting Bracket Instructions for  
Invacare®  
Tube Style Powerchair Armrests.**

- 1. Raise armrest and locate screw nearest end of armrest that attaches armrest pad to tubular frame.**
- 2. Remove screw and save for reuse.**
- 3. Place SnapIt! bracket under armrest tube so that tube is cradled in the pocket of the bracket.**
- 4. Reinsert screw through hole in SnapIt! bracket and tube and tighten.**
- 5. Snap convenience accessory into mounting bracket.**