

## Mounting Bracket Assembly Instructions for Merits® Powerchairs



**1. Raise arm and locate screw closest to end of armrest. Remove screw using an Allen Wrench**



**2. Insert screw into hole in mounting bracket and reattach into underside of armrest using Allen Wrench.**



**3. Snap convenience accessory into mounting bracket.**

**Enjoy!**

