

Instructions for installing SnapIt! System™ Mounting Arm on Pride Jazzy® Powerchair Armrests.

1. Raise Armrest.

2. Locate square receptacle.



3. Insert SnapIt!™ mounting arm into receptacle with clip facing up.

4. Tighten setscrew with Allen wrench until the arm is held snugly in place.

5. Do not overtighten.

6. Insert convenience accessory into the clip on the mounting arm.

Enjoy!