

Instructions for installing SnapIt! System™ Mounting Arm on Pride QJ6® Powerchair Armrests.

1. Raise Armrest.

2. Locate square receptacle.



3. Insert SnapIt!™
mounting arm into
receptacle with clip
facing up.

4. Tighten setscrew
with Allen wrench
until the arm is held
snugly in place.

5. Do not overtighten.

6. Insert convenience accessory into the clip on
the mounting arm.

Enjoy!