



3-Piece Camo Kit Instructions

Cut-To-Fit length Offers Special Sizing

The ForegripGuard and BarrelGuard are Cut-to-Fit products. They are triple stitched to allow easy cutting. Once cut, they **WILL NOT UNRAVEL!** *SIMPLY MEASURE, CUT, AND STRETCH ON.*

PROPER CARE AND HANDLING

*MAKE SURE GUN IS UNLOADED AND SAFETY IS ON.
NEVER POINT A GUN AT YOURSELF OR ANYONE ELSE.*

For maximum product life and proper gun care, please remove the entire 3-Piece Camo Kit from your gun when it is not in use. After removing the Camo Kit, wipe off gun with a dry towel. If your firearm is subjected to rain, snow, or moisture, remove the Camo Kit and wipe gun off as soon as possible. If using solvents on the exterior of the barrel, allow 24 hours for the solvents to evaporate before re-installing BarrelGuard.

www.beartoothproducts.com

--StockGuard--

Installation instructions for **Shotguns**

- 1) **MAKE SURE GUN IS UNLOADED AND SAFETY IS ON.**
- 2) Turn Stock Guard completely inside out (rubber should be on outside).
- 3) Slide smaller end of Stock Guard over the barrel down to the pistol grip.
- 4) Turn right side out.
- 5) Adjust for perfect fit.

Installation instructions for **Rifles**

- 1) **MAKE SURE GUN IS UNLOADED AND SAFETY IS ON.**
- 2) Turn Stock Guard completely inside out (rubber should be on outside).
- 3) Slide large end of StockGuard over butt stock.
- 4) Pull Stock Guard forward over stock until smaller end covers the pistol grip.
- 5) Pull StockGuard back or right side out covering the entire stock.
- 6) Adjust for perfect fit.

Using A Sling with the StockGuard

- 1) **MAKE SURE GUN IS UNLOADED AND SAFETY IS ON.**
- 2) Unscrew swivel stud.
- 3) Install StockGuard.
- 4) Move seam of StockGuard 3/4" to the left of the stud. Make a small cut directly above the stud. **DO NOT CUT INTO SEAM. THIS WILL CAUSE STITCHING TO UNRAVEL!**
- 5) Slide StockGuard back over swivel stud through hole, and re-fasten swivel stud.



--ForegripGuard--

Cut-To-Fit instructions - ForegripGuard for ALL Models

- 1) **MAKE SURE GUN IS UNLOADED AND SAFETY IS ON.**
- 2) Measure forearm with ruler, then add 1/4" to allow for shrinkage.
- 3) Using sharp scissors, cut the Neoprene to this measurement.

Installation instructions - ForegripGuard for Semi-Auto or Over/Under Models

- 1) ForegripGuard fits over the top of the barrel.
- 2) Turn ForegripGuard completely inside out.
- 3) Slide over barrel and forearm.
- 4) Turn ForegripGuard right side out.

The middle strip of Lycra should be centered evenly over rib and barrel. Adjust for perfect fit.

NOTE- You may need to cut additional slots for gas ports in some autos. Simply locate port and cut away covered area.

Installation instructions - ForegripGuard for Shotgun Pump Models

- 1) **MAKE SURE GUN IS UNLOADED AND SAFETY IS ON.**
- 2) Remove barrel from receiver.
- 3) Slide neoprene completely over forearm. Make sure middle Lycra strip is centered over top of forearm.
- 4) Attach corner pieces of Neoprene guard to corners of forearm.
- 6) Re-attach barrel, and adjust for perfect fit.

ForegripGuard continued

Installation instructions - ForegripGuard for Rifles

- 1) Foregrip Guard for rifles fits over the top of the barrel.
- 2) Turn ForegripGuard completely inside out.
- 3) Slide over barrel and forearm.
- 4) Turn ForegripGuard right side out, pulling back towards receiver.

The middle strip of Lycra should be centered evenly over rib and barrel. Adjust for perfect fit.

--BarrelGuard--

Cut-To-Fit instructions - BarrelGuard for ALL FIREARMS

- 1) **MAKE SURE GUN IS UNLOADED AND SAFETY IS ON.**
- 2) With ruler, measure the length of your barrel from the top of the forearm to the end of the barrel. Add 1/4" to allow for shrinkage.
- 3) Using sharp scissors, cut the end **OPPOSITE THE LOGO.**

Installation instructions - BarrelGuard for ALL FIREARMS

- 1) Point barrel of the unloaded gun away from you and others.
- 2) Slide neoprene over top of barrel and rib, pulling gently down until barrel is completely covered.
- 3) Adjust so seam is at the underside of the barrel.

NOTE- DO NOT COVER BARREL PORTS WITH NEOPRENE!

