

# COMB RAISING KIT



## SAFETY // HELPFUL TIPS

- ALWAYS MAKE SURE GUN IS UNLOADED AND SAFETY IS ON
- NEVER POINT GUN AT YOURSELF OR ANYONE ELSE

- Multiple inserts can be used simultaneously but the limit will be based on the shape and size of your stock.
- To ensure maximum product life and proper gun care, remove if subjected to moisture. Wipe off gunstock with dry towel and allow neoprene to dry completely before reinstalling.
- Do not install cover if an oil has recently been used on gunstock.
- This is a sewn product, some loose threads can be expected. Do not pull, simply cut with scissors at base of thread to remove and keep seam intact.



**5** Now that the cover is bunched by the pistol grip it is time to insert the foam.



**6** Next "tuck" the smaller end of the desired foam insert underneath the smaller opening of the cover.



**1** The neoprene is rubber backed, which helps keep the cover in place. To install, turn the cover completely inside out so the rubber is facing out.



- \* GUNS WITHOUT SCOPES GO TO STEP 2, THEN SKIP TO STEP 5
- \* GUNS WITH SCOPES GO TO STEPS 3



**2** With the seam on the bottom, pull the smaller opening over the barrel and continue pulling (and stretching where help is needed) until the cover is gathered by the pistol grip. Proceed to step 5.



**3** Pull the large opening over the butt plate first and begin to pull down towards pistol grip. The seam should be on bottom of stock (careful to help over the swivel stud to prevent snagging).



**4** Once the cover is mostly pulled on (still inside out), you will need to "stretch" the small opening over the butt plate (this is the hardest step). Then continue pulling until the cover is gathered by the pistol grip.



**7** Then hold foam in place as you turn the cover right side out allowing the rubber to grip the stock. Continue until the larger opening is back at the butt end and foam is completely covered.



**8** You may need to move foam into desired position with your fingers under the cover - then adjust for perfect fit.



**9** If the CRK looks like this, you have successfully completed installation.

**HAPPY SHOOTING!**



PROUDLY

SINCE 1996



To see the full line of Beartooth accessories, visit us at [www.beartoothproducts.com](http://www.beartoothproducts.com)