

## **Recoil Pad Kit Installation Instructions**

- 1) Insert desired pad size inside Slip-on Recoil Pad.
- 2) Carefully stretch neoprene Recoil Pad over butt plate and stock.
- 3) Adjust foam pad on buttplate in desired area.
- 4) Tuck fingers deeply under neoprene and pull tightly forward for optimum fit.

\*NOTE- for use with swivel stud, first unscrew stud, then make small incision in neoprene directly above swivel hole.  
**DO NOT CUT INTO SEAM!**