

installation steps&methods

- 1.Take out bracket(C+D), position the bores according to the product, stick into G, adjust the angle of bracket, bores should be in alignment with G, and then put H into G for fixing.
- 2.Take out(B+E+A), stick (B+E) into left and right side of(A), put(E)into(D), put(B) slip into round orifice of(C)through runner.